

E8 Series 60 Hz

reverse osmosis machine 57,000 to 144,000 gallons per day



figure 1: E8 Series 60 Hz

When you mention reverse osmosis (RO), SUEZ is the first name to come to mind. Our E-series RO machines (Figure 1) are designed for durable operation, high quality product water production, easy installation and straightforward control.

general properties

typical applications

- Process ingredient water
- Safe drinking water
- Boiler feed water
- Ion exchange pre-treatment

standard economy features

- Energy saving 400 ft² (37.2 m²) membrane elements
- SS high-pressure piping
- 1-micron pre-filter and SS housing
- Automatic inlet shut-off valve
- Burkert RO microprocessor controller

- Permeate and concentrate paddlewheel flow sensors
- Permeate conductivity sensor
- Permeate tank level monitoring
- SD card for collection of operating data
- ALARMS: Low inlet pressure, high temperature, high permeate conductivity, motor fault, and fill-time exceeded
- Remote machine on/off capability
- Feed water flush on shut down
- Panel-mounted pre-filter, post-filter, primary, and final pressure gauges

deluxe (DLX) features – in addition to ECN features

- Inlet pH sensor
- Chemical dosing pump for antiscalant dosing or pH adjustment
- Clean-In-Place pump plumbed, wired and mounted; remote tank
- ALARMS: Same as above plus high/low inlet pH, high permeate pressure

table 1: operating parameters

Operating Pressure	200-250 psig (13.8-17.2 bar)
Maximum Recovery	75%
Nominal Rejection	95-98%
Operating Temperature	55-85 °F (13-30 °C)
Minimum Inlet Pressure	30 psig (2 bar)
Design Temperature	77 °F (25 °C)

Find a contact near you by visiting www.suezwatertechnologies.com and clicking on "Contact Us."

*Trademark of SUEZ; may be registered in one or more countries.

©2017 SUEZ. All rights reserved.

table 2: materials of construction

Frame	Painted Carbon Steel
Membrane Elements	AG8040F-400
Membrane Housing	FRP
Low Pressure Pipe	Schedule 80 PVC
High Pressure Pipe	Stainless Steel
Motor Starters	NEMA 4

table 3: pump and motor

Pump Manufacturer	Tonkaflo*
Pump Type	Multi-stage, centrifugal
Materials	SS shell/housing, Noryl* internals
Castings	SS inlet/discharge
Motor	3-phase, TEFC, 460 VAC

table 4: E8 specifications - 60 Hz

model	E8-57K	E8-86K	E8-108K	E8-144K
ECN	1202846	1202850	1202833	1202835
DLX	1202284	1202286	1202287	1202288
flow specifications				
Recovery Range:	66-75%	66-75%	66-75%	66-75%
Permeate Rate: gpm (m ³ /h)	40 (9)	60 (14)	75 (17)	100 (23)
Concentrate Rate: gpm (m ³ /h)	21-13 (5-3)	30-20 (7-5)	39-25 (9-6)	52-33 (12-8)
pump and motor				
RO Pump Model	SS8510KA	SS8512KB	SS12508KC	SS24006KE
RO Motor: HP (KW)	15 (11.2)	20 (15)	25 (18.7)	40 (29.8)
CIP Pump Model: (DLX only)	SS5504G	SS5504G	SS8504G	SS8504G
CIP Motor: HP (KW)	5 (3.7)	5 (3.7)	7.5 (5.6)	7.5 (5.6)
membrane elements and filters				
Membrane Quantity	8	12	15	21
Array	1-1-1	2-1-1	3-2	3-2-2
Pre-Filter Quantity	7, RO.Zs 01-40-XK	7, RO.Zs 01-40-XK	7, RO.Zs 01-40-XK	7, RO.Zs 01-40-XK
connections				
Inlet: inch (cm)	2.0 (5.1)	2.0 (5.1)	2.0 (5.1)	3.0 (7.6)
Permeate: inch (cm)	1.5 (3.8)	2.0 (5.1)	2.0 (5.1)	2.0 (5.1)
Concentrate: inch (cm)	1.5 (3.8)	1.5 (3.8)	1.5 (3.8)	1.5 (3.8)
dimensions & weights				
Height: inch (cm)	76 (193)	76 (193)	76 (193)	76 (193)
Width: inch (cm)	153 (388)	153 (388)	153 (388)	153 (388)
Depth: inch (cm) ECN	42 (107)	42 (107)	42 (107)	42 (107)
Depth: inch (cm) DLX	91 (231)	91 (231)	91 (231)	103 (262)
Shipping Weight Estimate: lb (kg)	ECN	2600 (1200)	3000 (1360)	3400 (1500)
Shipping Weight Estimate: lb (kg)	DLX	2800 (1300)	3300 (1500)	3700 (1700)

