

BetzDearborn* DCL30

dechlorinating agent for industrial membrane applications

description and features

BetzDearborn* DCL30 is a very cost-effective product used to remove free and combined chlorine from reverse osmosis and ultrafiltration feedwaters. This liquid product is a high quality solution of sodium bisulfite (NaHSO₃).

Feedwaters to membrane systems often contain chlorine to treat and prevent microbiological growth prior to the membrane separation process. This chlorine, however, can irreversibly damage thin film composite membranes by oxidizing the membrane surface. The sodium bisulfite in BetzDearborn DCL30 quickly deactivates chlorine and protects membranes from damage.

Note: For potable or food-grade applications, BetzDearborn DCL32 should be used. See product fact sheet for maximum use levels and details.

chemistry of dechlorination

Deactivation of chlorine by sodium bisulfite:



application

4.44 ppm of BetzDearborn DCL30 are required to remove 1 ppm of chlorine, measured as total chlorine.

BetzDearborn DCL30 application dosages should be limited by the chlorine demand. It has been observed that an excess of sodium bisulfite in the RO feedwater may increase the incidence of microbiological growth in membrane systems.

Your SUEZ representative can assist you with identifying chlorine levels in your process and in defining the dosage requirements for BetzDearborn DCL30.

stability

Please refer to the Safety Data Sheet for stability information. The product may be slowly degraded by oxygen after the package is opened; the rate of degradation increases with higher temperatures. When using in an open day tank, do not use agitation and monitor the active concentration on a weekly basis. The product stability will decrease if diluted; consult with your SUEZ representative to determine the optimum dilution concentration and solution stability for your application.

packaging information

BetzDearborn DCL30 is a liquid material, available in a variety of containers and delivery methods. Contact your SUEZ representative for details.

safety precautions

A Material Safety Data Sheet containing detailed information about this product is available upon request.

Corrosion-resistant materials should be used for the storage and handling of this product. Discuss recommended materials of construction with you SUEZ representative.

Find a contact near you by visiting www.suezwatertechnologies.com and clicking on "Contact Us."

*Trademark of SUEZ; may be registered in one or more countries.

©2017 SUEZ. All rights reserved.